


Pushbutton Switches

Illuminated Pushbutton Switches

PB59 Series




PB59MTAA...



A Type Actuator
A Type Cap




PB59MTBB...



B Type Actuator
B Type Cap




PB59MTBC...



B Type Actuator
C Type Cap




PB59MTCD...



C Type Actuator
D Type Cap




PB59MTBBNZ...



B Type Actuator
B Type Cap
Full Color RGB *1




PB59MTBB2NZ...



B Type Actuator
B Type Cap
Full Color RGB *2




PB59MTBBZ...



B Type Actuator
B Type Cap
Full Color RGB *1



PB59MTBB2Z...



B Type Actuator
B Type Cap
Full Color RGB *2

HOW TO ORDER:

PB59

1 OPERATION:

- M Momentary
- 2 ACTUATION:
- T Tactile Actuation
- N Non-Tactile Actuation

3 ACTUATOR:

- A A Type (only for Cap A)
- A1 A1 Type (OP=2.5mm, TP=3.5mm) (only for Cap A)
- B B Type (only for Cap B & C)
- B1 B1 Type (OP=2.5mm, TP=3.5mm) (only for Cap B&C)
- C C Type (only for Cap D)

4

- A/A1/A2 SQ 12.0mm
- AC/A1C/A2C Protective Guard SQ 15.0mm
- B/B1 SQ 15.0mm
- BC/B1C Protective Guard SQ 17.4mm
- C/C1 SQ 10.0mm
- D Protective Guard
- DC
- 5 + 6 Without LED
- N Ultra Blue
- UG Ultra Red
- UC Ultra White
- UB Ultra Yellow
- UE

CAP TYPE:

F

- Pure Green
- Z Full Color RGB *1
- ZZ Full Color RGB *2
- NZ Full Color RGB *1
- 2NZ Full Color RGB *2

7 DIFFUSER PLATE COLOR:

- B White (Standard)
- C Red
- F Green
- G Blue
- E Yellow
- BB White (when indicate the cap color)

8 CAP COLOR:

- T Transparent (Standard)
- C Red
- F Green
- G Blue
- E Yellow
- S Silver
- JJ Transparent (when indicate the diffuser color)

9 CAP SYMBOL (Refer to Appendix):

- N Without Symbol
- K3 (Stabdard Symbols are Laser-Carving. If you wish printed Symbols, please add the code P in front, for example PK3, PE1)
- E1



Pushbutton Switches




























































































Illuminated Pushbutton Switches

PB59 Series

CAP SYMBOLS

Example:

K3  (Standard Symbols are Laser-Carving.
If you wish printed Symbols, please
add the code **P** in front, for example
PK3, PE1)
E1 

	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
A	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
B	A	B	C	D	E	F	G	H	I	J	CH5	CH6	DISK	PIP	C-KEY	CUT	TAKE	REC	ENG	PROD
C	K	L	M	N	O	P	Q	R	S	T	REPLAY	RET1	RET2	KEY ON	AUTO TAKE					
D	U	V	W	X	Y	Z	POWER	ON OFF	ON	OFF		USER A	USER B	USER C	USER D	USER E	USER F	USER G	USER H	USER I
E	OK		Auto	Enter	Start	STOP	OPEN	CLOSE	Exit	Move	USER J								M-1	
F	SET	Reset	Light	Alarm	Menu	Next	Back	Delete	Motor	Save						✓1	✓2			
G	Up	Down	Right	Left	Test	End	Insert	Lock	Print	+/-										
H	ESC	BC.	HOME	Health	D-LED 2	OC GENIE	VIDEO INPUT	dr CMOS	Green Power	Save OK										
I				F1	F2	F3	F4	F5	F6	F7										
J	F8	F9	F10	F11	F12	F13	F14	IN 1	IN 2	IN 3										
K	IN 4	IN 5	IN 6																	
L	+	-	x	÷	=	↑	→													
M																				
N	↑	→	↗	↖	▲	▶	◀	▶	◀	▶										
O																				
P				x	✓	⊖	Config.	TIME LINE	ME1	ME2										
Q	ME3	ME4	BGND 3D DVE1	BGND 3D DVE2	BUS COLOR	ME BUTTON LINK	*	INSERT	WIPE											
R		ALL		VP		COPY		RECORD MODE												
S			MUTE																	
T																				
U			chair	audio	radio															
V						CLEAR	CROSS WIND	AMMO TEMP	BARO PRESS	AIR TEMP										
W	BORE-SIGHT	CANT	LEAD	RANGE	MRS	ZERO	TEST	UD	LR											
X	ID	Dlep	MF	GALL		BAND	SETUP	MODE	LINK	FUNC.										
Y	SHIFT					DEL														
Z				RUN	2D	3D	CH1	CH2	CH3	CH4										